



USER GUIDE & MAINTENANCE RECOMMENDATIONS

Glassboard

Crystal Glass

February 2020



User Guide & Maintenance Recommendations

To clean glass boards quickly:

1. Spray a glass cleaner on the surface.
2. Rub with a clean, soft cloth.
3. Dry the surface.

To clean the surface more deeply:

1. Clean the glass with warm, soapy water.
2. Rinse surface with clear water.
3. Dry the surface.

Additional Details

Use a soft, clean rag to wash the surface.

Recommended Maintenance Frequency

Once a week or more frequently according to use.

Recommended Cleaning Brush

Clean, soft cloth

Recommended Markers

Markers from the brands Pilot, Pentel or Staedtler are excellent options. For easier writing without residue, we recommend using alcohol-based markers. Low-odor markers (water-based) give inferior results because the ink can leave residue while drying, making the board harder to clean.

How do we erase permanent marker lines?

The most effective way to remove lines from permanent markers is to write over them with a dry erase marker and then erase the lines. If the permanent marker lines resist this tactic:

1. Soak a rag with rubbing alcohol.
2. Rub the marks in a circular motion.
3. Rinse the surface with water and dry it with a clean, dry rag.
4. Repeat as necessary to eliminate all marks.

